
VINE 3 S MODELS **QUICK START**

Hold ⏻ to turn **ON**. LED will turn on, the player will “beep” *once* and play automatically. Hold ⏻ again to turn **OFF**. LED will turn off, the player will “beep” *twice* and stop playing.


Problems with the player? Try pressing the Reset button.







**Vine 3 S2 Pictured*



Full user manual: **https://shemishgrove.solutions/vine-3-s-um**